



Wearing Instructions For

Snowman



Costume Specialists

This is
Snowman
fully assembled.



If you have
any questions or
problems please call
Costume Specialists
at
1-800-596-9357

- This costume is designed to be worn by someone of an average build and approximately 5'7" to 6'1" tall.
- The wearer ought to be of reasonable strength and stamina.
- T-shirt and shorts are best worn under the costume. It's advisable that the wearer drink plenty of liquids before and after the event.
- The costume must be worn WITH shoes.
- Be sure to have a dress rehearsal. It takes two people about 10 to 15 minutes to put on the costume. Becoming comfortable in the costume before the event will insure the best performance.
- Have Fun!!

Wearing Instructions For

Snowman



This is
Snowman's
Parts List



Electrical Vest



Body



Hat Brim



Scarf



2 Endura Batteries and
VL-2 Charger



Shoe Covers



Shoe Bases

ADDITIONAL ITEMS NOT PICTURED:

- V-Mount (located in Electrical Vest)
- Y-Cable (located in Body)
- Waist Snap Hoop (located in Body)
- Set of 3 Support Straps (attached to Waist Hoop)
- 1 Dust Bags
- 2 Shoe Bags
- Charger Bag
- Cleaning Instructions
- Shipping Trunk



2 BSC Fans (located in
the Body)

Wearing Instructions For **Snowman**



1 Make sure all Batteries are fully charged.

Hold the Check button on the side of the Battery to see the charge level.



2 Load a fully charged Battery in to the V-Mount. And put the V-Mount into the pocket of the Electrical Vest.



3 If the Brim is not already attached, Velcro the Hat Brim onto the Costume's Hat.

Make sure to put the seam on the red band at the center back.



4 Have the wearer put on the Electrical Vest.



5 Place the wearer's foot into the Shoe Base. Secure the wearer's shoe in the sandal with the velcro.



6 Attach the velcro on the Shoe Base to the velcro on the Costume, making sure to line up the center front and the center back. This should be a snug fit.

Wearing Instructions For

Snowman




7 Reach inside of the Body to find the “Clutchie” at the top of the of the Costume, secure the Frame Extension with the velcro.



8 Lift the Body over the wearer’s head. The wearer should help by using the Frame Extension to lift.

Guide the Frame Extension into the pipes on the Vest.



9 Find the Y-Cable and plug it into the Power Cord on the V-Mount.

Let the Costume inflate. This will take about one minute.



10 Once inside, pull the skirt up to your waist and tighten the drawstring around your waist. This seals the Costume and allows the Costume to inflate.



11 Clip your suspenders into the clips on your Electrical Vest.

And adjust them to achieve the appropriate height.



12 Adjust the Hat Brim by holding the velcro in place at the top of the Hat band and pull down on the Brim to make it taut.

Wearing Instructions For

Snowman



13 Put on the Scarf making sure to line up the center back of the Scarf and the center back of the Body.

Wrap around the neck and drape one end over the other on the left shoulder.



14 Snowman is now ready to entertain!

Once the costume is inflated, have the wearer check the visibility.

The best visibility can be achieved by adjusting the length of the Support Straps. If the viewing area is too low, shorten the Support Straps which will raise the viewing area. If the viewing is too high, lengthen the Support Straps which will drop the viewing area. The Frame Extension should be raised and lowered, with the adjustments of the Support Straps, by moving the pegs up and down the Pipes.

BUT the weight of the Body should not be held by the Frame Extension.