



Wearing Instructions For

Red M&M



Costume Specialists

This is
Red M&M
fully assembled.



If you have
any questions or
problems please call
Costume Specialists
at
1-800-596-9357

- This costume is designed to be worn by someone of an average build and approximately 5'0" to 5'4" tall.
- The wearer ought to be of reasonable strength and stamina.
- T-shirt and shorts are best worn under the costume. It's advisable that the wearer drink plenty of liquids before and after the event.
- The costume must be worn WITH shoes.
- Be sure to have a dress rehearsal. It takes two people about 10 to 15 minutes to put on the costume. Becoming comfortable in the costume before the event will insure the best performance.
- Have Fun!!

Wearing Instructions For

Red M&M



This is
Red M&M
Parts List



Body



Shoes



Electrical Backpack w/
Frame Extension



2 Endura Batteries and
VL-2 Charger



2 Pr. Mitts



2 BSC Fans (located in
the Body)



V-Mount

ADDITIONAL ITEMS NOT PICTURED:

- Y-Cable (located in Body)
- 2 Dust Bags
- Charger Bag
- Cleaning Instructions

Wearing Instructions For **Red M&M**



1 Make sure that the Fans are secured to the corresponding velcro patches in the Body. The vent on the Fan should point up to the top of the Costume.



2 Put the Battery in the V-Mount plate and put the V-Mount plate into the pouch on the Backpack and zip it closed.



3 Put on the Mitts and snap them to the wrist of the Body.



4 Put on the Backpack and fasten the clips to fit securely.



5 Step into the Body and pull the inner legs up under your knees. Pull the Body up around you.



6 Velcro the Frame Extension to the "Clutchie" in the top of the Body.

Lift the Body by the Frame Extension over the wearer.

Insert the Frame Extension into the Backpack.

Wearing Instructions For

Red M&M



7 Plug the Y cable into the V-Mount plate. Zip up the Costume closed and let inflate. Inflation should take about 45 seconds.

If the fans don't start, check the connection between the V-Mount and Y-Cable. Then try a different Battery



8 Step into each Shoe, making sure that your foot is securely in the elastic inner shoe. Tuck the legs into the Shoes to fit smoothly.



9 Red M&M is now ready to entertain!

Once the costume is inflated, have the wearer check the visibility.

The best visibility can be achieved by adjusting the height of the Frame Extension.

If the viewing area is too high, lower the Frame Extension by moving the pegs down the Pipes.

If the viewing is too low, raise the Frame Extension by moving the pegs up the Pipes.

See the next set of pages for instruction on how to store the Costume.

Figure Eight Storage Instructions



1. Place the character upside down on the ground and locate the legs of the character.



2. Tuck the legs and arms together in the center of the body.



3. Grasp the edges of the hoop with an “over-under” placement of your hands.



4. Twist with one hand and push with the other hand so the hoop doubles over on-top of itself like a figure eight.



5. Place the now compact costume into the dust bag.