

White Bear







If you have any questions or problems please call Costume Specialists at 1-800-596-9357

- ☐ This costume is designed to be worn by someone of an average build and approximately 5'6" to 5'10" tall.
- ☐ The wearer ought to be of reasonable strength and stamina.
- ☐ T-shirt and shorts are best worn under the costume. It's advisable that the wearer drink plenty of liquids before and after the event.
- ☐ The costume must be worn WITH shoes.
- Be sure to have a dress rehearsal. It takes two people about 10 to 15 minutes to put on the costume. Becoming comfortable in the costume before the event will insure the best performance.
- □ Have Fun!!

White Bear




This is
White Bear's
Parts List



Backpack w/V-Mount
Bag



2 Endura Batteries and VL-2 Charger





Body



Shoe Bases





Vest



Bow Tie

ADDITIONAL ITEMS NOT PICTURED:

- V-Mount (located in Backpack)
- Y-Cable (located in Body)
- Waist Snap Hoop (located in Body)
- Set of 3 Support Straps (attached to Waist Hoop)
- 1 Dust Bags
- 2 Shoe Bags
- Charger Bag
- Shipping Trunk

White Bear






Check the Inventory. Be sure the Batteries are fully charged.



2 Insert a fully charged
Battery onto the
V-Mount Plate and slide it
into the Bag on the back of
the Backpack. Clip the Bag
closed, allowing the Power
Cord to hang out of the
Bag on the right hand side.



Put on the Backpack and clip waist belt closed. Adjust straps so they fit comfortably, just above the hips.



Reach into the
Costume leg and find
the Elastic Cuff. Step foot
into the cuff so that the top
Elastic sits at the knee,
and the bottom Elastic is
secure at the ankle.



Place the wearer's foot into the Shoe Base.
Secure the wearer's shoe in the sandal with the velcro.



Attach the velcro on the Shoe Base to the velcro on the Costume, making sure to line up the center front and the center back. This should be a snug fit.

White Bear





Inside the Costume there are three straps attached to a Hoop at the waist. Clip the two front straps to the top of the Backpack at each side. Adjust the straps at the top of the Backpack to achieve the appropriate height. These straps hold the weight of the Costume.



Clip the back strap to the top of the Backpack at the center back.



Adjust the Straps to adjust the height of the Costume. This may have to be done by the wearer once inside the Costume.



10 Plug Power Cord on Backpack into Y-Cable.



1 1 Pull the Costume over the wearer and the Backpack. Zip and velcro the Costume closed. Let the Costume inflate.

Inflation takes approximately 45 seconds!



12 Snap the Tail closed.

Costume Specialists

White Bear



13 Snap Bow Tie to body.



14 Snap Vest to body.



15 The Bear can also be worn without clothing.

(If Bear is wearing other garments, put them on at this time as alternate clothing.)



16 White Bear is now ready to entertain!

Once the Costume is inflated, have the wearer check the visibility.

The best visibility can be achieved by adjusting the length of the Support Straps.

If the viewing area is too low, shorten the Support Straps which will raise the viewing area.

If the viewing is too high, lengthen the Support Straps which will drop the viewing area.