



Wearing Instructions For **SHAGGY TEDDY BEAR**



This is
Shaggy Teddy Bear
fully assembled.



If you have
any questions or
problems please call
Costume Specialists
at
1-800-596-9357

- This costume is designed to be worn by someone of an average build and approximately 5'5" to 5'9" tall.
- The wearer ought to be of reasonable strength and stamina.
- T-shirt and shorts are best worn under the costume. It's advisable that the wearer drink plenty of liquids before and after the event.
- The costume must be worn WITH shoes.
- Be sure to have a dress rehearsal. It takes two people about 10 to 15 minutes to put on the costume. Becoming comfortable in the costume before the event will insure the best performance.
- Have Fun!!

Wearing Instructions For **SHAGGY TEDDY BEAR**



This is
Shaggy Teddy
Bear's
Parts List



Frame Extension



Body



Shoe Bases



2 Endura Batteries and
VL-2 Charger



2 BSC Fans (located in
the Body)



Backpack w/
V-Mount Bag

ADDITIONAL ITEMS NOT PICTURED:

- V-Mount (located in Backpack Bag)
- Y-Cable (located in Body)
- Waist Snap Hoop (located in Body)
- Set of 3 Support Straps (attached to Waist Hoop)
- 1 Dust Bags
- 2 Shoe Bags
- Charger Bag
- Shipping Trunk

Wearing Instructions For **SHAGGY TEDDY BEAR**



1 Check the Inventory.
Make sure the Batteries are fully charged.



2 Put on the Backpack and clip the belt. The belt should rest comfortably on the hips.



3 Insert a fully charged Battery onto the V-Mount Plate. Secure the Battery and zip the bag closed, allowing the Power Cord to hang out of the bag.



4 Reach into the Costume leg and find the elastic cuff. Step foot into the cuff so that the top elastic sits at the knee, and the bottom elastic is secure at the ankle.



5 Place the wearer's foot into the Shoe Base. Secure the wearer's shoe in the sandal with the velcro.



6 Attach the velcro on the Shoe Base to the velcro on the Costume, making sure to line up the center front and the center back. This should be a snug fit.

Wearing Instructions For **SHAGGY TEDDY BEAR**



7 Inside the Costume there are Three Straps attached to the Waist Hoop. Clip these straps to the top of the Backpack. Adjust the straps at the top of the Backpack to achieve the appropriate height. These straps hold the weight of the Costume.



8 Inside the Head there is a velcro tab. Attach the velcro on the Frame Extension to the velcro inside the Head.



9 While inserting the Frame Extension into the head of the Costume, pull the Costume over the Backpack and the wearer.



10 Insert the Frame Extension into the pipes on the back of the Backpack. If the height of the Costume is not appropriate, insert the Pins into the holes on the pipes to achieve a taller height.



11 Plug the Power Cord on the Backpack into the Y-cable. The fans should begin to run.



12 Zip and velcro the Costume closed. Let the Costume inflate.

Inflation takes approximately 45 seconds.

Wearing Instructions For
SHAGGY TEDDY BEAR



13 Shaggy Teddy Bear is
now ready to entertain!

Once the costume is inflated, have the wearer check the visibility.

The best visibility can be achieved by adjusting the length of the Support Straps.

If the viewing area is too low, shorten the Support Straps which will raise the viewing area.

If the viewing is too high, lengthen the Support Straps which will drop the viewing area.

The Frame Extension should be raised and lowered, with the adjustments of the Support Straps, by moving the pegs up and down the Pipes.

BUT the weight of the Body should not be held by the Frame Extension.