



# Wearing Instructions For **Easter Bunny**



Costume Specialists

This is  
Easter Bunny  
fully assembled.



If you have  
any questions or  
problems please call  
Costume Specialists  
at  
1-800-596-9357

- This Costume is designed to be worn by someone of an average build and approximately 5'7" tall.
- The wearer ought to be of reasonable strength and stamina.
- T-shirt and shorts are best worn under the Costume. It's advisable that the wearer drink plenty of liquids before and after the event.
- The Costume must be worn WITH shoes.
- Be sure to have a dress rehearsal. It takes two people about 10 to 15 minutes to put on the Costume. Becoming comfortable in the Costume before the event will insure the best performance.
- Have Fun!!

# Wearing Instructions For **Easter Bunny**

This is  
Easter Bunny's  
Parts List!



Jumpsuit



Body



Electrical Backpack



2 Support Straps

## ADDITIONAL ITEMS NOT PICTURED:

- V-Mount (located in Electrical Backpack)
- Y-Cable (located in Body)
- Dust Bag
- Shoe Bag
- Charger Bag
- Cleaning Instructions
- Shipping Trunk



Shoe Bases



Shoe Covers



2 BSC Fans  
(located in the Body)



2 Endura Batteries  
and VL-2 Charger



Frame Extension

# Wearing Instructions For Easter Bunny



**1** Check the Inventory. Make sure the Batteries are fully charged.

On the side of the Battery is a button push in to indicates how much life is left in the Battery.



**2** Insert a fully charged Battery into the V-mount Plate. Slide the Battery into the pocket on the back of the Backpack. Fasten the bag closed, allowing the Power Cord to hang out of the right side of the bag.



**3** If Jumpsuit is not on the Body put it on.

Step three and four will make it easier to put on the Shoe Bases later.



**4** If Shoe Covers are not on feet, put them onto the Costume. Velcro into place making sure to line up center front and center back.



**5** Put on Backpack and clip around waist. Adjust so the strap fits comfortably around waist, just above hips.



**6** Reach into the Costume legs and find the elastic cuffs. Step foot into the cuff so that the top elastic sits at the knee, and the bottom elastic is secure at the ankle.

# Wearing Instructions For Easter Bunny



**7** Place the wearer's foot into the Shoe Base. Secure the wearer's shoe in the sandal with the velcro.



**8** Attach the velcro on the Shoe Base to the velcro on the Costumes foot, line up the center front and the center back. This should be a snug fit.

Once the Shoe Bases are on let the clothes drape around the ankles of the Body and finish dressing.



**9** Inside the Costume there are Support Straps at each arm hole. Clip the straps to the top of the Backpack. Adjust the straps at the top of the Backpack to achieve the appropriate height. The straps will hold the weight of the Costume.



**10** Plug the Power Cord on the Backpack into the Y-Cable. The Fans should begin to run.



**11** Inside the Head of the Costume is a velcro tab called a "Clutchy". Velcro the Frame Extension to the Clutchy. Pull the Costume over the wearer and the Backpack.



**12** While inserting the Frame Extension into the Head of the Costume, pull Costume over the wearer and the Backpack. Insert Frame Extension into the pipes on the back of the Backpack.

# Wearing Instructions For **Easter Bunny**



**13** To adjust the height of the Costume, put Pins into holes on the pipes to raise the Frame Extension. The height may have to be determined after the wearer is inside the inflated Costume.



**14** Zip and velcro the Costume closed. Let the Costume inflate.

Inflation takes approximately 45 seconds.



**15** Snap Tail to Body and center into place.



**16** Pull the Clothes back up onto the Body. Have the wearer put their arms into Costume and snap the Collar to the Body around neck.



**17** Zip and velcro the Jumpsuit closed.



**18** Easter Bunny is now ready to entertain.

Wearing Instructions For  
**Easter Bunny**



**Once the costume is inflated, have the wearer check the visibility.**

**The best visibility can be achieved by adjusting the length of the Support Straps.**

**If the viewing area is too low, shorten the Support Straps which will raise the viewing area.**

**If the viewing is too high, lengthen the Support Straps which will drop the viewing area.**

**The Frame Extension should be raised and lowered, with the adjustments of the Support Straps, by moving the pegs up and down the Pipes.**

**BUT the weight of the Body should not be held by the Frame Extension.**