



Flippo



Costume Specialists

This is
Flippo
fully assembled.



If you have
any questions or
problems please call
Costume Specialists
at
1-800-596-9357

- This costume is designed to be worn by someone of an average build and approximately 5'6" to 5'10" tall.
- The wearer ought to be of reasonable strength and stamina.
- Shorts and a T-Shirt are best worn under the costume. It's advisable that the wearer drink plenty of liquids before and after the event.
- The costume must be worn WITH "street" shoes.
- Be sure to have a dress rehearsal. It takes two people about 10 to 15 minutes to put on the costume. Becoming comfortable in the costume before the event will insure the best performance.
- Have Fun!!

Wearing Instructions For

Flippo




Flippo's
Parts List



Body



Electrical Vest



Y-Cable
(located in Body)



1 pr Shoe Bases

Additional Parts



2 BSC Fans
(located in the Body)



2 Endura Batteries
and VL-2 Charger

1 Body Hoops
Set of 3 Suspender
Straps
(located in Body)

2 Dust Bags

Charger Bag

Cleaning
Instructions

Wearing Instructions For Flippo



1 Load a fully charged Battery in to the V-Mount. And put the V-Mount into the pocket of the Electrical Vest.



2 Have the wearer put on the Electrical Vest.



3 Reach into the costume leg and find the elastic cuff.

Step foot into the cuff so that the top elastic sits at the knee.



4 Inside the Body there are three Suspender Straps attached to a hoop. Clip these straps to the shoulders of the Vest pack. Have a helper clip the strap in the back. Adjust the straps to pull the legs tight.



5 Have the wearer hold Body off the floor.

Help place the wearer's feet on the Shoe Bases.

Secure the wearer's feet into the sandals with the Velcro.



6 Attach the Velcro on the Shoe Bases to the Velcro on the costume, making sure to line up the center front and center back.

This should be a snug fit. Adjust so that the feet have a full shape.

Wearing Instructions For Flippo



7 After the Body is attached to the Shoe Base, grip the Shoe Base Velcro through the foot.

Press firmly all the way around to ensure the Velcro is tightly sealed.



8 Plug the Y-Cable into the V-Mount. The Fans should begin to run.

IF THE FANS DON'T START, CHECK THE CONNECTION BETWEEN THE V-MOUNT AND Y-CABLE. THEN TRY A DIFFERENT BATTERY.



9 Pull the Body over wearer Head and zip the Body closed.

Let it inflate.

Inflation should take about 45 seconds.



10 Flippo is now ready to entertain!

The best visibility can be achieved by adjusting the length of the Support Straps.

Once the costume is inflated, have the wearer check the visibility.

If the viewing area is too low, shorten the Support Straps.

If the viewing is too high, lengthen the Support Straps.