



## Wearing Instructions For

# Mama Duck



Costume Specialists

This is  
Mama Duck  
fully assembled.



If you have  
any questions or  
problems please call  
Costume Specialists  
at  
1-800-596-9357

- This costume is designed to be worn by someone of an average build and approximately 5'6" to 5'10" tall.
- The wearer ought to be of reasonable strength and stamina.
- T-shirt and shorts are best worn under the costume. It's advisable that the wearer drink plenty of liquids before and after the event.
- The costume must be worn WITH shoes.
- Be sure to have a dress rehearsal. It takes two people about 10 to 15 minutes to put on the costume. Becoming comfortable in the costume before the event will insure the best performance.
- Have Fun!!

## Wearing Instructions For

# Mama Duck



This is  
Mama Duck  
Parts List



Electrical Backpack



Body



Dress



2 Endura Batteries and  
VL-2 Charger

### ADDITIONAL ITEMS NOT PICTURED:

- V-Mount (located in Electrical Backpack)
- Y-Cable (located in Body)
- Waist Snap Hoop (located in Body)
- Set of 3 Support Straps (attached to Waist Hoop)
- 2 Dust Bags
- Charger Bag
- Cleaning Instructions



Hat



2 BSC Fans (located in  
the Body)



Shoe Bases

# Wearing Instructions For **Mama Duck**



**1** Check the Inventory. Be sure the Batteries are fully charged.



**2** Insert a fully charged Battery into the NP Box and close lid. Clip the bag closed, allowing the Power Cord to hang out of the bag on the right hand side.



**3** Put on the Backpack and adjust the straps to a comfortable fit.



**4** Reach into the Costume leg and find the elastic cuff. Step foot into the cuff so that the top elastic sits at the knee, and the bottom elastic is secure at the ankle.



**5** Place the wearer's foot into the Shoe Base. Secure the wearer's shoe in the sandal with the velcro.



**6** Attach the velcro on the Shoe Base to the velcro on the Costume, making sure to line up the center front and the center back. This should be a snug fit.

## Wearing Instructions For

# Mama Duck



**7** Locate the three Support Strap connected to the Waist Hoop. Clip each strap to the clips located across the top of the Backpack. This will help to support the weight of the Costume.



**8** Pull the front of the Body up over the wearers head and plug the Power Cord attached to the Backpack into the Y Cable. The fans should begin to run. Zip the Costume closed. It should fully inflate in 30 to 45 seconds.



**9** Put on the Dress. Fasten the snaps on the collar of the Dress to the Body.



**10** Snap collar of the Dress to the Body in the back. Fasten the velcro closure on the back of the Dress.



**11** Put on the Hat. Fasten the snaps on the Hat to the snaps on the head.



**12** Mama Duck is now ready to entertain.

# Mama Duck



**Once the Costume is inflated, have the wearer check the visibility.**

**The best visibility can be achieved by adjusting the length of the Support Straps.**

**If the viewing area is too low, shorten the Support Straps which will raise the viewing area.**

**If the viewing is too high, lengthen the Support Straps which will drop the viewing area.**